

Hip Abduction Orthosis

How to measure for a Pre-fabricated Hip Abduction Orthosis:

1. Initial fitter is required to be proficient at bending metal.
(BENDING IRONS REQUIRED, NOT INCLUDED)
2. Measure thigh circumference at levels "A" and "B" to determine size for thigh assembly.
3. Measure waist circumference. This product will fit a patient with a waist circumference up to 65 inches.

Thigh Assembly Sizing Chart		
Size	Proximal (A)	Distal (B)
Small	15" - 22"	13" - 19"
Medium	18" - 25"	15" - 21"
Large	21" - 27"	17" - 23"

